



Ceco Door Products

INSTALLATION INSTRUCTIONS

Ceco Positive Pressure (UBC 7-2 / UL 10-C) Labeled Fire Door

THIS CECO DOOR HAS BEEN LABELED FOR COMPLIANCE WITH UBC 7-2, 1997 AND UL 10C. IT DOES NOT REQUIRE THE APPLICATION OF AN ADDITIONAL INTUMESCENT EDGE SEALING SYSTEM.

TO MAINTAIN THE VALIDITY OF THIS CERTIFICATION, THE DOOR INSTALLER MUST FOLLOW THESE INSTRUCTIONS. THE INSTRUCTIONS SHOULD BE KEPT ON FILE ON THE BUILDING PREMISES FOR VERIFICATION BY THE AUTHORITY HAVING JURISDICTION.

1. Verify that the door frame is compatible with the door and properly installed. See item # 4 below if a smoke rating is required.
2. Install hardware per the hardware manufacturer's instructions.
3. If a glass light kit is required, the kit must be listed in accordance with UBC 7-2, 1997, Parts I and II. Install the glass light kit per the glass light kit manufacturer's instructions.
4. When a smoke rating ("S" Label) is required, a fire rated smoke and draft control gasket must be installed in the opening. The gasket must be compatible with the door and frame type and is to be labeled showing compliance with UBC 7-2, 1997, Parts I and II. Install the gaskets per the gasket manufacturer's instructions.
5. Installation must comply with the requirements of NFPA 80.

Form AD-1090-F99-10C, 06/20/2003