

HANDING

To determine the hand of a door, view the door from the outside (the side that hinges are on is the hand of the door).

- If the door swings away from the viewer, the hand is regular hand, i.e., right or left hand.
- If the door swings to the viewer, the door is reverse swing, i.e., right hand reverse swing or left hand reverse swing.

All Steelcraft Doors and Frames are handed according to the following chart:

<p>Right Hand Door (swing in) Right Hand Frame</p>	<p>Left Hand Door (swing in) Left Hand Frame</p>
<p>Right Hand Reverse Bevel Door (swing out) Left Hand Frame</p>	<p>Left Hand Reverse Bevel Door (swing out) Right Hand Frame</p>
<p>Pair of Doors - LH Active (swing in) Double Door Frame - LH Active</p>	<p>Pair of Doors - RH Active (swing in) Double Door Frame - RH Active</p>
<p>Pair of Doors - LHRB Active (swing out) Double Door Frame - RH Active</p>	<p>Pair of Doors - RHRB Active (swing out) Double Door Frame - LH Active</p>

K - indicates Key side of the active door